

**Empty vial before splice.
Note: Vial shown clear
for illustration purposes.**



**Splices done on wiring using
crimp or wirenut type splice
connectors. Note: Make sure
wire sheeting is deep inside
vial interior.**



**Pull splice out of vial and
mix epoxy thoroughly. Pour
epoxy into vial to about 2/3
full. Shove spliced wires
down into epoxy until seated
at bottom of vial. Store
upright until epoxy hardens.**

