

Float Wiring Diagram





814 AIRWAY AVENUE
SUTHERLIN, OREGON
97479-9012

TELEPHONE:
(800) 348-9843
(541) 459-4449

WEBSITE:
www.orenco.com

Check the appropriate box for the float functions used in your system.



Wires

- - - Field Wire
- Float Wire White
- Float Wire Black

Splices

- Specs: waterproof twist-on wire connector

Float Types

- Specs: contact - normally open differential - no minimum power rating - signal