Float Arrangement Diagram



814 AIRWAY AVENUE SUTHERLIN, OREGON

97479-9012


TELEPHONE:


(541) 459-4449


FACSIMILE:

(541) 459-2884

Check the appropriate box for the float function (color code) used in your system.









Typical OSI float model: A

Specs: contact - normally open differential - no minimum power rating - signal

Possible substitutions: B,C,D



Typical OSI float model: B

Specs: contact - normally open differential - 3" min. power rating - signal

Possible substitutions: C.D.



Typical OSI float model: T

Specs: contact - normally closed power rating - signal





Drawing No.

differential - no minimum

*Terminal Link Rail is required (factory installed).

For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-S-6

*Remove pre-installed Terminal Link Rail from terminals. See Panel Wiring Diagram for instructions.

For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-S-5

*Remove pre-installed Terminal Link Rail from terminals. See Panel Wiring Diagram for instructions.

For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-S-7

Control Panel Series

S PT EDW-FA-S-3 EDW-FA-S-3 Rev 2.2 ©04/12/99