




Float Arrangement Diagram



Oreco Systems®
Incorporated

Check the appropriate box for the float function (color code) used in your system.

<input type="checkbox"/> (YG)R • <i>Factory Standard</i> •  <p>*Terminal Link Rail is required (factory installed).</p> <p>For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-SSF-233</p>	<input type="checkbox"/> YR  <p>*Remove pre-installed Terminal Link Rail from terminals. See Panel Wiring Diagram for instructions.</p> <p>For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-SSF-234</p>	<input type="checkbox"/> YGR  <p>*Remove pre-installed Terminal Link Rail from terminals. See Panel Wiring Diagram for instructions.</p> <p>For a wire splicing illustration of the above diagram, request Splice Box Wiring Diagram: EDW-SB-SSF-235</p>
--	--	---

Float Types

■ **Typical OSI float model: A**
Specs: contact - normally open
differential - no minimum
power rating - signal
Possible substitutions: B,C,D

814 AIRWAY AVENUE
SUTHERLIN, OREGON
97479-9012

TELEPHONE:
(541) 459-4449

FACSIMILE:
(541) 459-2884

Important: A high level condition in the sand filter will disable the septic tank pump in automatic mode.

Control Panel Series

MVP-SSF / PT

For use in two pump systems, sand filter side.

Drawing No.

EDW-FA-SSF-211

EDW-FA-SSF-211
Rev 3.0 ©1/4/02