

MVP-S DM TDR (Coburg)

DCN: EIN-CP-OP-2514

Rev: 9.0

Date: 03/14/18

Orenco’s Most Versatile Panel (MVP) line of control panels includes an easy-to-use programmable logic unit that incorporates many timing and logic functions. This panel will accommodate time of day restricted or on-demand systems. The panel’s default mode of operation is on-demand. This document describes each mode of operation.

Alarm and Data Screens:

Alarm and data screens have been included with the panel to assist with panel monitoring and troubleshooting. The following alarm and data screens have been included in your panel. Navigation between the screens is accomplished by using the up and down arrow keys. See “**Screen Navigation**” section for more details.

Screen	Description	Data Type*
Alarm Screens†		
1	Time clock not set	
2	High level alarm	
3	Low level alarm	
Data Screens		
4	Float status and timer mode (default screen, see fig 1)	
5	Pump cycles at top of screen and pump run time beneath	T
6	High level alarms at top of screen and low level alarms beneath	T
7	Power faults at top of screen and hours in service beneath	T
8	Pump cycles at top of screen and pump run time beneath	R
9	High level alarms at top of screen and low level alarms beneath	R
10	Power faults at top of screen and time since reset beneath	R

† Alarm screens will only be displayed when alarms are active and include a date and time stamp of when the alarm started.

* Screens with “T” in the lower right corner have totalized values for the data. Screens with “R” in the lower right corner have resettable data and display the accumulated values since the last reset. To reset the accumulated values, hold the silence button on the panel for 10 seconds.

Float Status and Time of Day Restricted Mode Screen:

This default screen will display the condition of the floats and the operation mode of the panel. If the floats are lifted out of sequence, this screen will display “Float Error” while showing the float status.




Figure 1. Float Status and Time of Day Restricted Mode Screen

Digital Input and Digital Output Screens:

The unit will activate various inputs and outputs as it operates (see Figure 2).




Figure 2. Input & Output Screens

Knowing what conditions cause the inputs and outputs to activate can be a helpful installation and troubleshooting tool. The input functions will vary based on the mode of operation of the panel. The following inputs and outputs have been used with your panel:

#	Functions:	Activation Conditions:
Inputs (On-Demand Mode)		
1	Redundant Off & Low Level Alarm Float	Float in up position
2	On & Off Float	Float in up position
3	Not Used	
4	High Level Alarm	Float in up position
5	Push To Silence	Pushbutton is pressed
Inputs (Time of Day Restricted Mode)		
1	Redundant Off & Low Level Alarm Float	Float in up position
2	Timer On & Off Float	Float in up position
3	Not Used	
4	High Level Alarm / Override Timer Float	Float in up position
5	Push To Silence	Pushbutton is pressed
Outputs		
1	Pump	Pump is called to run
2	Level Alarm Light	Level Alarm Light is activated
3	Audible Alarm	Audible Alarm is activated
4	General Alarm	Alarm condition exists

Screen Navigation:

The screens are arranged in the order shown in Figure 3 below. To move between screens, use the four arrow keys. The screens of interest are shown in bold. Additional built-in screens will be present, but do not contain useful information.




Figure 3. Screen Layout

Panel Operation:

This panel supports two different modes of operation based on selected parameter settings. See the "Setting Instructions" for this panel for information on how to change the mode of operation and other adjustable parameters.

On-Demand (Default Operation):

Your control panel can perform the float functions listed below.

High Level Alarm: This float activates the pump when lifted. The pump will run until the Pump On/Off Float is disabled. This float also activates the alarm light (steady) and audible alarm when lifted for longer than the high level alarm delay. The audible alarm may be silenced by pressing the illuminated PUSH TO SILENCE button on the front of the control panel. The alarm light (steady) will remain on until the float is lowered, and the audible alarm will reactivate in 12 hours if condition is not corrected.

Pump On: This float activates the pump when lifted. The pump will run for the minimum run time.

Redundant Off & Low Level Alarm: This float turns off the pump when lowered for more than 2 seconds. This float is a secondary off float, which will operate if the Pump Off float fails. Pumping will be

Time of Day Restricted:

Your control panel can perform the float functions listed below.

Time Clock:

The time clock will control when the pump will normally be allowed to operate in automatic mode. Standard pump dosing will be enabled during the time clock on time.

Note: The logic controller time & date must be set accurately on this control panel for correct timing of pump activation. If power is off for longer than 80 hours the time & date will have to be reset. The panel will run in On-Demand mode if the time & date is not set.

High Level Alarm: This float activates the pump for the override on time, regardless of the time clock setting. This also float activates the alarm light (steady) and audible alarm when lifted for longer than the high level alarm delay. The audible alarm may be silenced by pressing the illuminated PUSH TO SILENCE button on the front of the control panel. The alarm light (steady) will remain on until the float is lowered, and the audible alarm will reactivate in 12 hours if condition is not corrected.

Timer On & Off: This float activates the timer function when lifted. If the float is up during the restricted time schedule and the off time has expired, the pump will activate until the float is lowered.

Redundant Off & Low Level Alarm: This float turns off the pump when lowered for more than two seconds. This float is a secondary off float, which will operate if the Timer On & Off float fails. Pumping will be disabled in both the automatic and manual modes. This float also activates the alarm light (flashing) and audible alarm. The audible alarm may be silenced by pressing the illuminated PUSH TO SILENCE button on the front of the control panel. The alarm light will remain flashing until the float is lifted, and the audible alarm will reactivate in 12 hours if condition is not corrected.