

MVP-S DM Reference Chart

Program Code: SI112-80

Input Functions (Timed Dose):

1. RO & Low Level Alarm Float
2. Timer On & Off Float
3. Override Timer On & Off Float
4. High Level Alarm Float
5. Push to Silence
6. Alarm Test Switch (Optional)

Conditions for activation:

Float in up position
Float in up position
Float in up position
Float in up position
Pushbutton is pressed
Switch is activated

Alt. Input Functions (Demand):

2. Off Float
3. On Float

Conditions for activation:

Float in up position
Float in up position

Output Functions:

1. Pump
2. Level Light
3. Audible Alarm
4. General Alarm (Optional)

Condition for activation:

Pump is called to run
Alarm Light is activated
Audible Alarm is activated
Alarm condition exists

Built In Screens:

Built in screens include: time & date, digital inputs, and digital outputs. To view these screens, press the down arrow repeatedly until a built in screen appears, then use the left and right arrow keys to change between screens.

Alarm and System Data Screens:

Alarm screens appear during alarm conditions. System data screens include float status, pump run data, and alarm activity. Screens with a "T" in the lower right contain totalized values. Screens with a "R" in the lower right contain resettable values. To change between these screens, press the up and down arrow keys.

Selecting Blocks for Viewing or Adjusting:

To begin the process to set parameters, press the down arrow repeatedly until the last screen is shown, then press 'ESC'.

Parameter Name:	Description:	Time Range:	Timed/Demand:
HL Alm Delay	High Level Alarm Delay	MM:SS	Both
Off Time	Timer Off Time	MM:SS	Timed
On Time	Timer On Time	MM:SS	Timed
Ovr Off Time	Override Timer Off Time	MM:SS	Timed
Ovr On Time	Override Timer On Time	MM:SS	Timed
Min Ovr Time	Minimum Override Time	MM:SS	Timed
Min Run Time	Minimum Run Time	MM:SS	Demand
TimeDoseMode	Time Dose Mode		Both

EIN-CP-REF-148
Rev 7.9 © 04/20/18

MVP-S DM Reference Chart

Program Code: SI112-80

Input Functions (Timed Dose):

1. RO & Low Level Alarm Float
2. Timer On & Off Float
3. Override Timer On & Off Float
4. High Level Alarm Float
5. Push to Silence
6. Alarm Test Switch (Optional)

Conditions for activation:

Float in up position
Float in up position
Float in up position
Float in up position
Pushbutton is pressed
Switch is activated

Alt. Input Functions (Demand):

2. Off Float
3. On Float

Conditions for activation:

Float in up position
Float in up position

Output Functions:

1. Pump
2. Level Light
3. Audible Alarm
4. General Alarm (Optional)

Condition for activation:

Pump is called to run
Alarm Light is activated
Audible Alarm is activated
Alarm condition exists

Built In Screens:

Built in screens include: time & date, digital inputs, and digital outputs. To view these screens, press the down arrow repeatedly until a built in screen appears, then use the left and right arrow keys to change between screens.

Alarm and System Data Screens:

Alarm screens appear during alarm conditions. System data screens include float status, pump run data, and alarm activity. Screens with a "T" in the lower right contain totalized values. Screens with a "R" in the lower right contain resettable values. To change between these screens, press the up and down arrow keys.

Selecting Blocks for Viewing or Adjusting:

To begin the process to set parameters, press the down arrow repeatedly until the last screen is shown, then press 'ESC'.

Parameter Name:	Description:	Time Range:	Timed/Demand:
HL Alm Delay	High Level Alarm Delay	MM:SS	Both
Off Time	Timer Off Time	MM:SS	Timed
On Time	Timer On Time	MM:SS	Timed
Ovr Off Time	Override Timer Off Time	MM:SS	Timed
Ovr On Time	Override Timer On Time	MM:SS	Timed
Min Ovr Time	Minimum Override Time	MM:SS	Timed
Min Run Time	Minimum Run Time	MM:SS	Demand
TimeDoseMode	Time Dose Mode		Both

EIN-CP-REF-148
Rev 7.9 © 04/20/18

MVP-S DM Reference Chart

Program Code: SI112-80

Input Functions (Timed Dose):

1. RO & Low Level Alarm Float
2. Timer On & Off Float
3. Override Timer On & Off Float
4. High Level Alarm Float
5. Push to Silence
6. Alarm Test Switch (Optional)

Conditions for activation:

Float in up position
Float in up position
Float in up position
Float in up position
Pushbutton is pressed
Switch is activated

Alt. Input Functions (Demand):

2. Off Float
3. On Float

Conditions for activation:

Float in up position
Float in up position

Output Functions:

1. Pump
2. Level Light
3. Audible Alarm
4. General Alarm (Optional)

Condition for activation:

Pump is called to run
Alarm Light is activated
Audible Alarm is activated
Alarm condition exists

Built In Screens:

Built in screens include: time & date, digital inputs, and digital outputs. To view these screens, press the down arrow repeatedly until a built in screen appears, then use the left and right arrow keys to change between screens.

Alarm and System Data Screens:

Alarm screens appear during alarm conditions. System data screens include float status, pump run data, and alarm activity. Screens with a "T" in the lower right contain totalized values. Screens with a "R" in the lower right contain resettable values. To change between these screens, press the up and down arrow keys.

Selecting Blocks for Viewing or Adjusting:

To begin the process to set parameters, press the down arrow repeatedly until the last screen is shown, then press 'ESC'.

Parameter Name:	Description:	Time Range:	Timed/Demand:
HL Alm Delay	High Level Alarm Delay	MM:SS	Both
Off Time	Timer Off Time	MM:SS	Timed
On Time	Timer On Time	MM:SS	Timed
Ovr Off Time	Override Timer Off Time	MM:SS	Timed
Ovr On Time	Override Timer On Time	MM:SS	Timed
Min Ovr Time	Minimum Override Time	MM:SS	Timed
Min Run Time	Minimum Run Time	MM:SS	Demand
TimeDoseMode	Time Dose Mode		Both

EIN-CP-REF-148
Rev 7.9 © 04/20/18

MVP-S DM Reference Chart

Program Code: SI112-80

Input Functions (Timed Dose):

1. RO & Low Level Alarm Float
2. Timer On & Off Float
3. Override Timer On & Off Float
4. High Level Alarm Float
5. Push to Silence
6. Alarm Test Switch (Optional)

Conditions for activation:

Float in up position
Float in up position
Float in up position
Float in up position
Pushbutton is pressed
Switch is activated

Alt. Input Functions (Demand):

2. Off Float
3. On Float

Conditions for activation:

Float in up position
Float in up position

Output Functions:

1. Pump
2. Level Light
3. Audible Alarm
4. General Alarm (Optional)

Condition for activation:

Pump is called to run
Alarm Light is activated
Audible Alarm is activated
Alarm condition exists

Built In Screens:

Built in screens include: time & date, digital inputs, and digital outputs. To view these screens, press the down arrow repeatedly until a built in screen appears, then use the left and right arrow keys to change between screens.

Alarm and System Data Screens:

Alarm screens appear during alarm conditions. System data screens include float status, pump run data, and alarm activity. Screens with a "T" in the lower right contain totalized values. Screens with a "R" in the lower right contain resettable values. To change between these screens, press the up and down arrow keys.

Selecting Blocks for Viewing or Adjusting:

To begin the process to set parameters, press the down arrow repeatedly until the last screen is shown, then press 'ESC'.

Parameter Name:	Description:	Time Range:	Timed/Demand:
HL Alm Delay	High Level Alarm Delay	MM:SS	Both
Off Time	Timer Off Time	MM:SS	Timed
On Time	Timer On Time	MM:SS	Timed
Ovr Off Time	Override Timer Off Time	MM:SS	Timed
Ovr On Time	Override Timer On Time	MM:SS	Timed
Min Ovr Time	Minimum Override Time	MM:SS	Timed
Min Run Time	Minimum Run Time	MM:SS	Demand
TimeDoseMode	Time Dose Mode		Both

EIN-CP-REF-148
Rev 7.9 © 04/20/18