
## EZ SERIES® SINGLE PHASE DUPLEX

Single Phase, Duplex Demand Dose Float Controlled System for Pump Control and System Monitoring



The EZ Series® duplex control panel is designed to control two (alternating) 120, 208, 240 VAC single phase pumps in water and sewage installations. The alternating action equalizes pump wear. In addition to the alternating pump control, this system provides override control should either pump fail.

The EZ Series® duplex control panel features a backlit LCD display on the inside of the front cover for programming and system monitoring, including: float status, elapsed time pump run, cycle counter, alarm counts (high water/power fail), float error count, auxiliary alarm counter, timer override count (TD only).

Optional mounting post has removable access door for easy wiring. The post can be mounted in the ground directly, over a 4x4, or conduit. This panel is available with optional duo alarm for local code compliance; and optional EZconnex® float connection system.

## **COMPONENTS**

- Enclosure base measures 10 x 8 x 6 inches (25.4 x 20.32 x 15.24 cm); NEMA 4X enclosure (ultraviolet stabilized thermoplastic with removable mounting feet for outdoor or indoor use) includes locking latch as standard
- 2. Red alarm beacon provides visual check of alarm condition
- Exterior Alarm Test/Silence switch allows horn and light to be tested and horn to be silenced in an alarm condition; alarm automatically resets once alarm condition is cleared
- Two sets of circuit breakers: one for each pump power circuit; another for control and alarm power
- 5. Power relays control pumps by switching electrical lines
- 6. Float connection terminal block with auxiliary alarm contact
- 7. Incoming control/alarm power & pump power terminal block
- 8. Control Power indicator light
- 9. Alarm Power indicator light
- 10. Pump Run indicator lights
- 11. Duplex controller (touch safe housing) for pump control:
  - Backlit LCD display shows system information including: pump elapsed time (hh:mm), pump events (cycles), and alarm condition (counts)
  - b. Menu/Enter button used for viewing panel settings
  - c. Set/Change button used for programming panel settings
  - d. Pump 1 and Pump 2 Push To Run momentary switches pump activates when pressed
  - e. Control and Alarm Power shorted condition indicators
- 2. Alarm horn provides audio warning of alarm condition (83 to 85 decibel rating located inside panel on cover, not shown)

Note: Options, voltage, and amp range selected may change enclosure size and component layout.

**Note:** Schematic/Wiring Diagram and Pump Specification Label are located inside the panel.









| EZS  | 4          | _       |                 | 1<br>ALARM   | W               | STARTING  | PUMP FULL | 4<br>PUMP   | FLOAT SWITCH     | 3A6A8AC10E1              |             |
|--|------------|---------|-----------------|--|-----------------|---|-----------|-------------|------------------|--------------------------|-------------|
| PANEL  | MODEL      | . I YPE |                 | ACKAGE   | RATING          | DEVICE  | LOAD AMPS | DISCONNECTS | APPLICATION      | OPTIONS (LISTED BELO     | (W)         |
| CONTROL PAN  | NEL        | /       | EZS             |  |                 |   |           |             |                  |                          |             |
| MODEL TYPE / 4 Single Phase Duplex (includes Options |            |         |                 |  | udes Options 3  | A6A8AC10E15A as standard) EZS Duplex Base Price |           |             |                  |                          |             |
| ALARM PACKA  | /          | 1       | Alarm Pac       | kage (includes   | Alarm Package   |   |           |             |                  |                          |             |
| ENCLOSURE RA   | 1          | W       | Weatherpr       | oof, NEMA 4X   | Alailii Fackaye |   |           |             |                  |                          |             |
| STARTING DEVICE                                      |            |         | 1               | 120/208/240V Enclose   |                 |   |           |             |                  | Enclosure Rating         | sure Rating |
|  |            |         | 9               | 120V only  |                 |   |           |             |                  |                          |             |
| PUMP FULL  |            |         | 0               | 0 - 7 FLA  |                 |   |           |             |                  | Starting Device          |             |
| LOAD AMPS  |            |         | 1               | 0 - 7 FLA  7 - 15 FLA  15 - 20 FLA  Circuit Product(a) 120V (calact STARTING DEVICE Option 0 above)  |                 |   |           |             |                  | J                        |             |
|  |            |         | 2   15 - 20 FLA |  |                 |   |           |             | 8                | Pump Full Load Amps      |             |
| PUMP   |            | 1       | 4               | Circuit breaker(s) 120V (select STARTING DEVICE Obtion 9 above)  |                 |   |           |             | Pump Disconnects |                          |             |
| DISCONNECT   |            |         |                 | Circuit Breaker(s) 120/208/240V (select STARTING DEVICE Option 1 above)  |                 |   |           |             |                  |                          |             |
| FLOAT SWITC  | OAT SWITCH |         | H_              | Circuit Breaker(s) 120/208/240V (select STARTING DEVICE Option 1 above)  Floats - Pump Down (select Option 17 below)  EZconnex® Float Switch System (select Option 34 or 35 below) |                 |   |           |             |                  |                          |             |
| APPLICATION  |            |         | E               |  |                 |   |           |             |                  | Float Switch Application |             |
|  |            |         | Х               | No Floats  |                 |   |           |             |                  |                          |             |
|  |            |         |                 |  |                 |   |           |             |                  | Total Options            |             |
|  |            |         |                 |  |                 |   |           |             |                  | TOTAL LIST PRICE         |             |

| OPTIC | DESCRIPTION  | OPTIONS      | DESCRIPTION   |
|-------|--|--------------|---|
| 1J    | Duo Alarm Inputs   | 19F          | Fourth Float to Separate Alarm Function from Lag                      |
| ✓ 3A  | Alarm Flasher (Included as standard)   | 22G          | 2 1/2" Hub Installed with 6 Hole Cord Seal                            |
| ✓ 6A  | Auxiliary Alarm Contact, Form A (Included as standard)   | 34D <b></b>  | EZconnex® 4-Port, 25', with 10' Floats (3) / Pipe Clamp, Sealing Plug |
| ✓ 8A  | Display Board - Includes: ETM Counter, Events (Cycles) Counter, Alarm Counter (included as standard) | 34E          | EZconnex® 4-Port, 50', with 10' Floats (3) / Pipe Clamp, Sealing Plug |
| VOA   | Alarm Counter (included as standard)   | 34G <b>■</b> | EZconnex® 4-Port, 25', with 20' Floats (3) / Pipe Clamp, Sealing Plug |
| ✓ 101 | Lockable Latch - NEMA 4X (included as standard)  | 34H          | EZconnex® 4-Port, 50', with 20' Floats (3) / Pipe Clamp, Sealing Plug |
| 101   | Mounting Post (Factory installed with 2.5" cord seal)  | 35D <b>■</b> | EZconnex® 4-Port, 25', with 10' Floats (4) / Pipe Clamp               |
| / 15/ | Control/Alarm Circuit Breaker (Included as standard)   | 35E <b>■</b> | EZconnex® 4-Port, 50', with 10' Floats (4) / Pipe Clamp               |
| 16/   | 10' Cord in Lieu of 20' Cord (per Float)   | 35G          | EZconnex® 4-Port, 25', with 20' Floats (4) / Pipe Clamp               |
| 161   | 15' Cord in Lieu of 20' Cord (per Float)   | 35H <b>■</b> | EZconnex® 4-Port, 50', with 20' Floats (4) / Pipe Clamp               |
| 160   | 30' Cord in Lieu of 20' Cord (per Float)   |              |   |
| 161   | 40' Cord in Lieu of 20' Cord (per Float)   |              |   |
| 170   | Sensor Float® / Internally Weighted (per Float) - Mercury  |              |   |
| 171   | Sensor Float® / Externally Weighted (per Float) - Mercury  |              |   |
| 170   | SJE MilliAmpMaster™ / Pipe Clamp (per Float) - Mechanical  |              |   |
| 17H   | SJE MilliAmpMaster™ / Externally Weighted (per Float) - Mechanical                                   |              |   |
| 17.   | Sensor Float® / Pipe Clamp (per Float) - Mercury   | ]            |   |

■ EZconnex® mechanically-activated, narrow angle float switches with quick release connections